


## SIZING / MEASURE HEAD CIRCUMFERENCE / SELECT HELMET SIZE

Guide for Helmet Sizing. ATS fast Helmet Systems were created to accommodate the greatest number of users in the helmet sizes that best fit their heads. To determine your helmet and chinstrap sizes, refer to the sizing chart. While measuring, make sure to pull the measuring tape tightly up against your head and face. After taking a measurement, find your size by consulting the corresponding guide. Choose the larger of the two sizes if one guide recommends a different size than the other.



### 1. MEASURE HEAD CIRCUMFERENCE

Use a tape measure to determine the maximum head circumference above the ears. Record the measurement.

### 2. SELECT HELMET SIZE

Referring to the table below (in centimeters), select the helmet size based on head circumference.



### HELMET SIZING GUIDE

	<u>S</u>	<u>M</u>	<u>L</u>	<u>XL</u>
<u>Head Circumference (cm.)</u>	53-56	56-59	59-62	62-65
<u>Head Circumference (inch)</u>	20 <sup>7</sup> / <sub>8</sub> - 22	22 - 23 <sup>1</sup> / <sub>4</sub>	23 <sup>1</sup> / <sub>4</sub> - 24 <sup>3</sup> / <sub>8</sub>	24 <sup>3</sup> / <sub>8</sub> - 25 <sup>3</sup> / <sub>8</sub>
<u>HEAD SIZE (US)</u>	up to 7	up to 7 <sup>3</sup> / <sub>8</sub>	up to 7 <sup>5</sup> / <sub>8</sub>	up to 8 <sup>1</sup> / <sub>8</sub>

For users who do not fit our standard sizing configurations!  
 please contact ATS Group USA Customer Service:  
 email: [support@atsgroupusa.com](mailto:support@atsgroupusa.com)  
 tel: 314-301-9998.